


RRG-3617K BELT SANDER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	61001	Motor Housing	30	61035	Screw (M3x8)
2	61002	Guard	31	61036	Spring Pin (3x10)
3	6T-620003	Air Inlet	32	61037	Screw (M2x5)
4	6T-620004	Throttle Lever	33	061038	Ball Bearing (2) (684zz)
5	62005	Valve Stem	34	61039	Idle Pulley Shaft
6	62006	Valve	35	61040	Spring
7	30107	O-Ring (3.9x1.9)	36	61041	Tension Bar
8	62008	Spring	37	61042	Bushing
9	62009	O-Ring (14.5x1.5)	38	61043	Idle Pulley
10	62010	Spacer	39	61044	Spring
11	62011	Retaining Ring (RTW-18)	40	61045	Bracket
12	61012	Spacer	41	61046	Screw (M3x6)
13	051825	Ball Bearing (607zz)	42	61048	Spring Pin (2.5x8)
14	61014	Rear End Plate	43	61049	Spring
15	61015	Rotor	44	61050	Safety Lever
16	61016	Rotor Blade (4)	45	61249	Lock Pin (3x11.8)
17	61017	Key (3x3x10)	46	6T-620052	Grip
18	61018	Cylinder	47	51540-228	Safety Bar
19	61019	Front End Plate	48	51541-12	Spring
20	061020	Ball Bearing (628zz)	49	40337	Spring Pin (3*18L)
21	61021	Cap	50	40130	O-Ring (8.8*1.7)
22	61222	Drive Pulley	51	6T-620007	Screw
23	63042	Hexagon Nut (M6)	52	PN02001308	Pin (2*13.8)
24	61024	Shoe	53	10014	Hex. Key Wrench (4mm)
25	40343	Bolt (M5x16)	54	6T-620032	Screw (2) (M4*8L)
26	61026	Dust Cover	55	40147	Spring Washer (2)
27	6T-620030	Screw (M4x25L)	56	6T-620034	Nut (M4)
28	62056-11S	Muffler	57	6T-620031	Lever Support
29	62032	Screw (M4x8)			

6W-6100-RA01