


RRI-BCP08H2 CORDLESS TRANSDUCERIZED TOOL (3-8 NM)



Index No.	Part No.	Description	Q'ty
1	33101-NPA	Upper Housing	1
2	33102-NPA	Lower Housing	1
3	000-0930	Screw (ø3×14L)	12
4	000-0332	Screw (M3×6L)	2
5	33110-NPA-01	Cover	1
6	32176-NPA-01	LCM Board	1
7	B86IWT	Connector Wire	2
8	0-151018	Screw (ø2.6×6L)	4
9	32083-NPA-01	Brushless Motor ;w/driver	1
10	32046-NPA-02	Transducer	1
11	0-101066	Screw (M4×11L)	2
12	0-431022	O-Ring (P26)	1
13	00-41255	O-Ring (S7)	2
14	33242-NRA-01	Sleeve Coupling	1
15	33249-NPA-09	Sun Gear	1
16	D39SC180B-4	Washer	1
17	33249-NPA-11	Planet Gear	3
18	000-2415	Needle Bearing (INA-K357)	3
19	32051-NPA-03	Gear Cage Assembly	1

Index No.	Part No.	Description	Q'ty
20	D39SC108B	Washer	1
21	33249-NPA-06	Planet Gear	3
22	32051-NPA-04	Gear Plate Assembly	1
23	32049-NPA-01	Gear Ring	1
24	33243-NPA-01	Shaft	1
25	32041-NPA-01	Front Cover Assembly	1
26	000-3011	Snap Ring (STW-11)	1
27	000-3833	Steel Ball (ø3)	2
28	D42ID144A	Quick Change Holder	1
29	D48ID144A	Spring	1
30	D39ID144A	Hold Spacer	1
31	D44ID144A	Anvil Collar	1
32	B76IWT	PC Board	1
33	B09IWT#B1	F/R Valve (1set×2pcs)	1
34	D48IWT	Spring	1
35	32009-NPA-01	Trigger Assembly	1
36	D48PW15	Spring	1
37	C39PW15-3	Washer	1
38	33110-NPA-02	Cover	1